



## Instructions


SECOP

XV Compressors 160-264V, 50/60Hz with 105N5xxx Series Controllers











## Instructions

SECOP

XV Compressors 160-264V, 50/60Hz with 105N5xxx Series Controllers







<u> </u>	Max. pressure	Max. pressure is 20 bar. Abrupt pressure drop > 3 bar/sec is not permitted.		
<u> </u>	Evacuation	Two-sided evacuation (suction and discharge side) is essential.		
<u> </u>	Supply voltage	230 V (+15 % / - 30 %), 50/60 Hz, only with electronic controller Refer to XV controller <i>Instructions</i> for wiring diagrams.		
<u></u>	Oil charge	The compressor is already charged with 115 ml oil (5 cSt mineral). No oil should be removed or refilled.		
	Mounting instructions Compressor service	https://www.secop.com/products/technical-literature-guidelines/ https://www.secop.com/solutions/compressor-qa-tools/compressor-service/		

Shipment positions of refrigeration appliances								
Horizontal	Connectors up	Electrical lead-in up	Connectors down	Electrical lead-in down	Base plate up			

Secop accepts no responsibility for possible errors in catalogs, brochures, and other printed material. Secop reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary to specifications already agreed. All trademarks in this material are the property of the respective companies. Secop and the Secop logotype are trademarks of Secop GmbH. All rights reserved. www.secop.com